

THE FRESNEL RELATIONS

EXPERIMENTAL PHYSICS 2: EXERCISE 1 FREJA GAM & PETER ASP HANSEN

The Fresnel relations are investigated using a laser and prism setup, in which the reflected and transmitted light is detected. These measurements are taken for p-polarized and s-polarized light from which we can compare experimental data to all four of the Fresnel relations. These measurements seemed to agree with the theoretical predictions.

Introduction

This report discusses how the intensity and direction of light is affected when it is sent towards a transparent object, with a refractive index different to air. A laser beam was sent towards a semicircular prism, and the intensity of both the transmitted and reflected beam was detected. Furthermore, the refractive index of the prism was found, using the angles of refraction of the transmitted light.

Theory

Imagine a light beam travelling in a medium with refractive index n_1 . When the light beam reaches the boundary between medium n_1 and medium n_2 , it will either be refracted or reflected. The outgoing angles are relatively easy to find, as we can use Snell's law ($n_2 \sin \theta_2 = n_1 \sin \theta_1$) to find the refracted angle. Due to the law of reflection, the outgoing reflected angle θ_1 is the same as the incoming angle.

However if we want to know about the intensities or polarization of the light beam, the four Fresnel relations are highly useful.

The Fresnel relations come in two different forms, one for the amplitude reflection and transmission coefficients (r_p, t_p, r_s, t_s) and a second for the intensity reflection and transmission coefficients (R_p, T_p, R_s, T_s). We use indices p and s to distinguish between the parallel and perpendicular polarization. The relationship between the two forms can be described using the following formulas:

$$R = r^2 \quad , \quad T = \frac{\cos \theta_2}{\cos \theta_1} \frac{n_2}{n_1} t^2$$

We will primarily use the second form, as we later will see that these values are more comparable to our experimental data. The intensity reflection and transmission coefficients can be calculated the

following ways:

$$R_p = \frac{\tan^2(\theta_1 - \theta_2)}{\tan^2(\theta_1 + \theta_2)}$$

$$T_p = \frac{\sin 2\theta_1 \sin 2\theta_2}{\sin^2(\theta_1 + \theta_2) \cos^2(\theta_1 - \theta_2)}$$

$$R_s = \frac{\sin^2(\theta_1 - \theta_2)}{\sin^2(\theta_1 + \theta_2)}$$

$$T_s = \frac{\sin 2\theta_1 \sin 2\theta_2}{\sin^2(\theta_1 + \theta_2)}$$

Another notable feature of the coefficients is that they must sum up to 1 ($T + R = 1$), because as the light ray interferes a medium and splits up into a reflected and a refracted part the sum of their intensities has to equal the intensity prior to the interaction.

We can plot the intensity reflection and transmission coefficients for different incident angles in a certain medium, to note some special characteristics. Below are the coefficients plotted for light travelling from glass into air and from air into glass respectively.




Figure 2: Plots of the intensity reflection and transmission coefficients for air ($n=1$) to glass ($n=1.5$).




Figure 3: Plots of the intensity reflection and transmission coefficients for glass ($n=1.5$) to air ($n=1$).

In figure 2 and 3 we pay close attention to two particular angles denoted θ_B and θ_C . The first angle is called Brewster angle, θ_B . From both plots we can see that this angle is given by $R_p(\theta_B) = 0$, which means it is the angle where there is no reflected p-polarized light. We calculate the angle in the following way:

$$\theta_B = \arctan\left(\frac{n_2}{n_1}\right)$$

The other angle is the critical angle θ_C . This angle is illustrated in the second plot by the black asymptote. The critical angle is an angle where no light can exit the medium. It is also called the angle for total internal reflection. We calculate the angle in the following way:

$$\theta_C = \arcsin\left(\frac{n_1}{n_2}\right)$$

Setup and methods

The experimental setup consists of a laser, which sends light through a lens and a polarizer, after which the light is transmitted or reflected in the prism. The polarizer placed before the prism was set at 45° so equal amounts of s- and p-polarized light would be transmitted. After the light is transmitted or reflected in the prism, it passes through a lens and a s/p polarizer before it hits the detector, which translates the signal to an intensity measured in voltage in PicoScope. The detector could be placed so that it either captured the reflected or the transmitted light, and for every incident angle, both the reflected and transmitted light was measured.

¹If time had permitted we would have liked to also have recorded some data for light travelling from glass to air. The way to do that is by turning the prism, where we instead of hitting the prism on the flat side, we would have hit it on the curved side.




Figure 4: Experimental setup measuring the reflected light.



Figure 5: Experimental setup measuring the reflected light.

Measurement plan

The plan for the experiment was as follows:

- First lab session: During the first lab session majority of the time was spent on figuring out the setup and actually getting usable measurements.
- Second lab session: Measurements for air to glass were made. In particular we were able to record data for s-polarized light.
- Third lab session: More measurements for glass to air, this time for p-polarized light and calculating the refractive index of the material.¹

Experimental data

The outcome of the experiment was the following experimental data

θ_1 [degree]	Detector angle [degree]	Transmitted t [V]	σ_t [mV]	Reflected r [V]	σ_r [mV]
0	0	2.6	2.6	0.07	0
10	3.5	2.44	4.5	0.1	1.5
20	7	2.17	2	0.1	0.5
30	10.5	1.9	4	0.12	1.2
40	15	1.53	5	0.15	1
50	20	1.18	0.5	0.2	0.5
60	25	0.85	0.7	0.28	0.5
70	32	0.48	0.5	0.44	1
75	37	0.25	0.5	0.54	1.5
80	40	0.2	1	0.7	0.7
85	42	0.07	1	1.2	0.2

Tabel 1: Raw data for s-polarization

θ_1 [degree]	Detector angle [degree]	Transmitted t [V]	σ_t [mV]	Reflected r [V]	σ_r [mV]
0	0	2.931	5.178	0.02181	0
10	3	2.604	5.569	0.02181	0
20	6	2.2	2.589	0.03909	0.188
30	9	1.575	0.8947	0.03711	0.1742
40	13	1.188	0.2601	0.02181	0
50	18	1.016	1.199	0.02181	0
60	23	0.6635	4.797	0.02181	0
70	30	0.4183	0.5591	0.05065	1.085
75	33	0.2846	2.732	0.09444	0.5304
80	37	0.1802	6.623	0.1695	2.757
83	40	0.8942	7.665	0.2195	0.9605
85	42	0.5496	2.97	0.2941	0.2552

Tabel 2: Raw data for p-polarized light

Data processing


Before we plot the experimental data versus the theoretical data, we will calculate the refractive index n_2 inside the prism using the incident- and detector angles. We can calculate the outgoing angle by subtracting the detector angle from the incident angle. This is due to geometrical reasons in the setup, see figure 6.

Below is an example calculation for $\theta_1 = 10^\circ$ in table 2 where $n_1 = n_{air} = 1$.

$$\theta_2 = \theta_1 - \text{detector angle} = 10 - 3 = 7^\circ$$

We plug these values into Snell's law

$$n_2 = n_1 \frac{\sin \theta_1}{\sin \theta_2} = \frac{\sin(10)}{\sin(7)} = 1.43$$



Figur 6: Geometrical argument for θ_2

If we take the average value for n_2 for all θ_1 in table 2 we get an average refractive index of

$$n_2 = 1.44 ; \sigma = \pm 0.02$$

The refractive index is solely depending on the mediums, thus it is fair to assume that it is the same for s polarized light.

From our raw data of the s- and p polarization we can determine $R_{s/p}$ and $T_{s/p}$. We assume that all of the refracted light is transmitted out through the glass, although in reality a small fraction will be reflected inside the glass.

$$R_{s/p} = \frac{r}{r+t}$$

$$T_{s/p} = \frac{t}{r+t}$$

These coefficients are only measurements of how much of the total measured light that are respectively reflected and refracted. By calculating $R_{s/p}$ and $T_{s/p}$ this way, we ensure that they always sum up to 1 even as the sum of t and r decreases, as seen in table 1 and table 2.

Likewise we can determine their uncertainties using the formulas below and isolating for σ_{R_s} and σ_{T_s} respectively:

$$\frac{\sigma_{R_s}}{R_s} = \frac{\sigma_r}{r} + \frac{\sigma_r + \sigma_t}{r+t}$$

$$\frac{\sigma_{T_s}}{T_s} = \frac{\sigma_t}{t} + \frac{\sigma_r + \sigma_t}{r+t} [1]$$

The processed data is presented below in table 3 and 4.

θ_1	T_s	σ_{T_s}	R_s	σ_{R_s}
0	0.974	0.002	0.02622	0.00003
10	0.972	0.004	0.0279	0.0007
20	0.969	0.002	0.0312	0.0003
30	0.941	0.004	0.0594	0.0007
40	0.911	0.006	0.0893	0.0009
50	0.855	0.001	0.1449	0.0005
60	0.752	0.001	0.2478	0.0007
70	0.522	0.001	0.478	0.002
75	0.316	0.001	0.684	0.004
80	0.222	0.002	0.778	0.002
85	0.0551	0.0008	0.945	0.001

Tabel 3: Processed data for s-polarization

θ_1	T_p	σ_{T_p}	R_p	σ_{R_p}
0	0.993	0.003	0.00739	0.00001
10	0.992	0.004	0.00831	0.00002
20	0.983	0.002	0.0175	0.0001
30	0.977	0.001	0.0230	0.0001
40	0.9820	0.0004	0.018028	0.000004
50	0.979	0.002	0.02102	0.00002
60	0.97	0.01	0.0318	0.0002
70	0.892	0.004	0.108	0.003
75	0.75	0.01	0.249	0.004
80	0.52	0.03	0.48	0.02
83	0.29	0.03	0.71	0.02
85	0.16	0.01	0.843	0.009

Tabel 4: Processed data for p-polarization

Results

We can plot the processed data to get a visual image of how well it matches the theoretical predictions.




Figure 7: Plot of processed data for s polarization





Figure 8: Plot of processed data for p polarization

As an aid to comparing the experimental data to theoretical predictions we made a fit of experimental data with our best-fit parameter as n_2 . For the s polarized data, the fit differs slightly from

the theoretical function, but for the p polarized it almost aligns perfectly. Even though it might seem a bit unexpected, this is due to the nature of the function - small changes in n_2 barely changes the function.

Discussion

The data differs slightly from the theory, but overall it fits nicely to a function on the same form as the theoretical expressions for $R_{s/p}$ and $T_{s/p}$. There are multiple possible reasons for the deviation. One of the most likely sources of error, is the assumption that all of the light that is being transmitted when it hits the prism is also transmitted out of the prism, and hits the detector. This assumption is necessary for us to compare the data to the theoretical function, as it only describes the behavior of the light when it hits the flat side of the prism, and not what happens once it is inside. In reality, some of the light is reflected inside the prism, and exits as T' , which is illustrated in figure 9.




Figur 9: Illustration of reflected and transmitted light

This T' is very small, both in theory, but also when we tried to measure it - it was simply too small of a signal to detect with the noise present. Despite this, it could very well be a major reason for the deviation in the data, since we generally detect less transmitted light than expected, which is exactly what the neglect of T' would cause.

Another source of error, or at least something worth mentioning, is that as θ_1 increased, the beam

was spread increasingly when it hit the detector, which resulted in the total detected light, both the reflected and transmitted, decreased. This can be seen in figure 10, where it is clear that not all of the light passes through the slit, which obviously leads to less intensity detected. Due to the way it was processed, where it was converted to fractions of the total light, it should not affect the data in theory, but it is still a possible source of error.



Figur 10: Laser beam spreading

Finally, it is also possible that the components used in the experiment could also be at fault for the deviation.

Conclusion

In conclusion to the experiment, we see enough similarities between experimental data and our theoretical predictions, the Fresnel relations, to say that we have experimentally verified them. This conclusion is based upon a thorough investigation, where we for instance compared a fit of our experimental data to the theoretical prediction. We could thereby compare the refractive index, and conclude that the slight deviation likely was caused by two limitations in the setup which creates a systematic error for large θ_1 .

Litteratur

- [1] IB Physics data booklet, https://www.iisjaipur.org/International_Wing/physics_Data_booklet.pdf
- [2] Lab manual: The Fresnel Relations